



The 'All-rim' bead breaker is a portable tool to allow the rapid and safe removal of a truck tyre from a wheel rim.


- Especially suitable for EVA wheel rims.
- Gently breaks the bead on the most stubborn of tyres.
- Simple, safe and reliable.
- Takes only seconds to fit and operate.
- Does not use a 'screw down drive'.
- Does not require an air supply.
- Angled geometry ensures the tyre bead is pushed down parallel to wheel rim wall.
- Sculptured & polished foot plate is kind to tyre walls.
- 1 bolt fixing gives a stable operating platform.
- Fully portable (only weighs 18.5Kg)
- Comes with painted & plated finish.
- Comes with FREE 6 tonne Bottle Jack.
- Optional Adaptor Bar for satisfying all wheel configurations.



RAM-ROD

manufacturing

DISTRIBUTED BY



RAM-ROD

manufacturing

DISTRIBUTED BY

